



INSTALLATION, OPERATION & MAINTENANCE INSTRUCTIONS

1455 Kleppe Lane ♦ Sparks, NV 89431-6467 ♦ (775) 359-4712 ♦ Fax (775) 359-7424
E-mail: haws@hawsco.com ♦ website: www.hawsco.com

No. 0002080222 (17)

Model 9082 Antimicrobial Preservative Concentrate Eyewash Additive

TO ORDER MORE EYE WASH STATION PRESERVATIVE CONCENTRATE:

Contact your nearest Haws Representative or call Haws Customer Service at
1-888-640-4297, Sparks, Nevada.

WARNING:

1. MUST BE DILUTED WITH **POTABLE** WATER. DO NOT PUT DIRECTLY INTO EYES. Do not use if tamper evident seal is broken or missing.
2. Contact with the eyes and mucosa can cause irritation, redness and pain.

Mixing Instructions

Follow instructions on the side of each bottle. Units with capacities of 5 gal - 20 gal (18.9 L – 75.7 L) should be mixed with the full 8 oz (236 ml) contained in each bottle. It is recommended that the tentative potable water be replaced every 120 days. (After any 15-minute testing per ANSI Z358.1-2014, refill tank with clean potable water and add contents of new 9082 Antimicrobial Preservative Concentrate Eyewash Additive, following instructions on the side of each bottle).

Storage Instructions

Product should be stored between 68° F - 77° F
(20° C - 25° C)
Use before expiration date.

36 Month shelf life after date of manufacture.

© 2019 Haws® Corporation – All Rights Reserved

HAWS® and other trademarks used in these materials are the exclusive property of Haws Corporation.